

FIG. 1




FIG. 2




FIG. 3




FIG. 4

Argument	Direction	relatedStateVariable
InstanceID	IN	A ARG TYPE InstanceID
ServerRTSPURL	OUT	RTSPURL

FIG. 5

Variable Name	Req.or Opt.1	Data Type	Allowed Value	Default Value	Eng. Units
RTSPURL	0	string			

FIG. 6

Argument	Direction	relatedStateVariable
MulticastGroupJoinAddress	IN	RTSPURL

FIG. 7

Argument	Direction	relatedStateVariable
MulticastGroupLeaveAddress	IN	RTSPURL